

Linear Actuator

Fig. ESX01/02

Model规范:

- ESX01/02-31: Supply VoltageAC220V, 3-float
- ESX01/02-11: Supply VoltageAC24V, 3-float
- ESX01/02-16: Supply VoltageAC24V, DC0~10V / 4~20mA
Control Signal and Feedback Signal

使用事项:

- Delivery: Actuator, valves and accessories are packaged and supplied separately.
- Maintenance: Maintenance-free
- Automatic adjustment: When debugging the valve, with valve stroke adaptive function and manual device, easy to install and debug actuator control signal output accurate, with linear adjustment valve use, can achieve a perfect equal percentage Control curve.

Schema



Model Overview:

Model	Supply Voltage	Signal	Stroke	Force	Speed	Manual
ESX01-16	AC24V	DC 0~10V/ 4~20mA	20mm	1000N	0.33mm/s	Adjusting wrench
ESX01-11		3-Float				
ESX01-31						
ESX02-16	AC24V	DC 0~10V/ 4~20mA	40mm	1800N	0.23mm/s	Adjusting wrench
ESX02-11		3-Float				
ESX02-31						

Notice

1. Actuator must be horizontal;
 2. Do not use force on the drive during installation;
 3. The thread connected with the valve must be standard thread
 4. The valve and pipeline should be kept clean before installation;
 5. The valve and pipe recommended horizontal installation, can be installed vertically, but not inverted;
 6. Ensure that the pipes and valves are insulated and do not wrap the Actuator in the thermal insulation layer.
- Note: If the product is damaged due to improper installation or harsh working medium, We only provide paid services.